



Filling Holes and Cracks With 2 Part Epoxy

After installation and before sanding, holes and cracks ¼" and larger may be filled with a dark filler in areas of high traffic. This kit consists of 16 oz. of custom-pigmented epoxy resin, 8 oz. of epoxy hardener, measuring cups, stirrers and a pair of latex gloves. Each kit should spot fill holes in between 600 square feet and 800 square feet of flooring. **Please follow mixing instructions and precautions on containers.**

All "through" holes that are to be filled, should be "backed" with pieces of paper towels, wood chips or sawdust to ¼ - ½ of the depth of hole. (A small punch, screwdriver or similar tool works well to set backing) This helps to substantially reduce epoxy leakage and the amount of epoxy used. Work in a small (100 square feet -200 square feet) area at a time. This will make it easier to keep track of which holes have been backed and will keep your epoxy batches small. Larger batches of mixed epoxy harden faster. **Start with small batches until you become familiar with rate of hardening.**

Pour a small amount of mixed epoxy in each backed hole to "seal" the hole and allow to dry 3-4 hours or longer. After this initial fill has dried for a sufficient time the hole can be filled, by pouring, to the top of plank. Allow to harden overnight before sanding and finishing.



FSC Supplier
SCS-COC-002514